

## For Bulk Liquid Storage



## Assembly Manual








JIING SHIN ENTERPRISE CO.,LTD
No.128, Hua 7th St., Daliao Shiang, Kaohsiung County 83163, Taiwan.
TEL:886-7-7874716 FAX:886-7-7873660 E-mail:jsec@jsec.com.tw


www.jsec.com.tw www.paperibc.com

## **PaperIBC Components**

A set of PaperIBC consists of:

- 1.BOX
- 2.CASSETTE LINER
- 3.SELF LOCK SINGLEWALL TOP COVER
- 4.BOTTOM CORRUGATED PAD (B Flute) 5.INNER CORRUGATED PAD (AB Flute)
- 6.OUTER PE LINER







JIING SHIN ENTERPRISE CO.,LTD
No.128, Hua 7th St., Daliao Shiang, Kaohsiung County 83163, Taiwan,
TEL:886-7-7874716 FAX:886-7-7873660 E-mail:jsec@jsec.com.tw



# PaperIBC Assembly Step 1

- 1) Place the bottom corrugated pad on the pallet and then the box.
- 2) Square the box and ensure it is on the same footprint as the pallet at all times.
- 3) Fold the inner corrugated pad along the scored line, place it in the bottom of the box fully unfolded.










### PaperIBC Assembly

#### Step 2

- 1)Open the cassette package and remove the protective covering. Remove the locking ring located at the inlet fitment and put aside for later use.
- 2)Quick coupling assembly with hose(optional). This is just only one of the method before connecting to your filling station.
- 3)Fold the cassette package with the connected hose and place it in the bottom of the box fully [unfolded].

CAUTION: Before folding the cassette package, please ensure all exposed metal parts on the quick coupling are properly wrapped and secured with protective covering [eg:cloth] to prevent from cutting the PE liner.












## PaperIBC Assembly Step 3


- 1)With your finger, reach out to the dispensing fitment and lightly pull it out.
- 2)Insert the locking ring into the discharge port and begin tightening the locking ring. Connect the cassette package to the filling station. The package is now ready for filling.














## PaperIBC Assembly

## Step 4

- 1)Cover the box with outer PE liner bag.
- 2)Assemble the top cover and cover the box with it. 3)Strapped the box 4-way with the pallet.













JIING SHIN ENTERPRISE CO.,LTD No.128, Hua 7th St., Daliao Shiang, Kaohsii. TEL:886-7-7874716 FAX:886-7-7873660



## PaperIBC Dispensing

- 1)Unscrew the dispensing cap from the dispensing fitment.
- 2) Separate the cutter from the cap.
- 3) With the cutter facing the liner, reinsert it and thread 2" ball valve into the dispensing fitment. Ensure that the valve is at off position before threading.
- 4) Turn the valve on.




















JIING SHIN ENTERPRISE CO.,LTD
No.128, Hua 7th St., Daliao Shiang, Kachsiung County 83163, Taiwan.
TEL:886-7-7874716 FAX:886-7-7873660 E-mail:jsec@jsec.com.tw




## PaperIBC Accessories and Tools

#### **Accessories and Tools(Optional)**

- 1. Ball valve
- 2. Squaring tool & Fill bridge

- 3. Quick coupling and black adaptor
- 4.Locking ring tool







JIING SHIN ENTERPRISE CO.,LTD
No.128, Hua 7th St., Daliao Shlang, Kaohsiung County 83163, Taiwan.
TEL:886-7-7874716 FAX:886-7-7873660 E-mail:jsec@jsec.com.tw

